The Strap

There is a soft fabric strap that extends from a slot in the side of the Twiddler's case and attaches to a Velcro pad on the bottom. This strap goes around the back of your hand and holds the Twiddler in position for typing or pointing. When you receive your Twiddler, decide which hand you would like to use the Twiddler and slide the strap into the groove on that side. **Be careful!** The fit may be snug. If it is, grasp the strap as close to the Twiddler as possible and gently, but firmly, slide the strap into the groove. Holding on further down the strap and pulling may cause the strap to tear.

Most users select their **non-dominant** hand, leaving their dominant hand free to do other tasks. Select the hand that feels most comfortable for you.



The Dots

There are two 1cm Velcro dots included in the accessory box. They are intended for strap management. The single sided dot can be stuck to the side of the Twiddler opposite to the hand you are using. eg: Left hand usage, place dot on right hand side of the Twiddler.



This allows you to fold the strap upwards and keep it out of the way.



The double sided dot can be stuck to the end of the strap so that it can be folded back upon itself to keep it out of the way.





From:
https://www.mytwiddler.com/doc/ - **Twiddler**

Permanent link:
https://www.mytwiddler.com/doc/doku.php?id=wiki:fabricstrap

Last update: **2022/10/21 22:11**